

Installation Manual

Bonnet Hinge Kit Ford XR XT XW XY PFEBHFD04



Typical Installation

- 1. Remove the bonnet and remove factory hinges and hand tighten supplied button headed bolts into the threads in the body and if the threads are damaged or corroded, re-tap them. The holes in the body are 5/16"-18 tap and the bonnet use a 5/16"-18 tap.
- 2. Position each hinge on the correct side and attach the hinge to the inner body fender with the 5/16" x 1-1/2" button headed bolts. Use the 2 washers on the rear bolts. Before tightening the bolts completely move the hinges up or down so the bolt is centred in the slot.
- 3. With the hinges in the lowered position measure between the fenders, across the bonnet brackets, and compare the spacing of the holes in the brackets to those in the bonnet. This may help in accurately positioning the hinges before the bonnet is bolted on.
- 4. Each hinge has a gas strut to hold the bonnet open. The gas strut should be attached to the hinge after the hinge is installed but before the bonnet is attached. The body or thicker part of the strut should be attached to the ball stud at the higher point on the hinge so that the shaft will be oiled by gravity.
- 5. Attach the bonnet to the hinges with the 5/16" x 1-1/4" button headed bolts. Slide the bonnet forward as far as possible before tightening the bolts. This will assure that the bonnet will not hit the cowl as it is lowered. Lower the bonnet CAREFULLY, watching the clearance front and back as well as both sides. Adjust the bonnet on the hinge brackets as needed for clearance.
- 6. Adjust the bonnet height. Once the bonnet closes completely, check the height of the bonnet at the rear corners. The hinges are shipped with the height adjustment in the lowest position so if the bonnet is too low, raise it by adjusting the short link with the rod end bearings. Adjusting the height this way will also move the bonnet forward, so the bonnet may have to be repositioned on the hinge brackets. Tighten the jam nuts when adjustment is complete.



EMAIL: sales@proflow.com.au PHONE: 1300 879 879