

PROFLOW

Universal Lead Set

The Proflow universal lead sets come with the spark plug ends already crimped at the factory. These kits come with both conventional and HEI distributor cap terminals and boots.

Kit Includes

2 x Ignition lead 140 cm
2 x ignition lead 115 cm
2 x ignition lead 100 cm
2 x ignition lead 58 cm
1 x coil lead 50 cm

9 x conventional terminals
9 x conventional lead boots
9 x HEI terminals
9 x HEI lead boots

- ① Place the lead onto the spark plug and route up to the cap . Make sure to clear any moving parts and exhaust. Place lead into holders if used to ensure the desired length is measured.
- ② Cut the lead at the desired length and slide the rubber boot onto the lead using silicon spray or dielectric grease.
- ③ Strip the outer silicon layer 20-25mm to expose the conductor and trim any fibres off with blade.
- ④ Fold over the conductor and place into terminal.
- ⑤ Crimp using a crimp tool and squeeze firmly until the terminal tabs are folded over securely crimped to the spark plug wire.
- ⑥ Check to make sure you have a solid connection on the cable, this would also be a great time to check the resistance of each wire to ensure you have continuity.
- ⑦ Then simply slide the boot over the terminal end and repeat each step.

