



## Installation Manual

### 2000kg Low Profile Car Ramps (Pair)

#### PFERR-CW1000KIT

Included Items	QTY
PFERR-CW1000KIT Low Profile Car Ramps	2
PFERR-CW1000KIT Carry bag	1

**WARNING:** PLEASE READ ALL INSTRUCTIONS BEFORE PROCEEDING. PROFLOW WILL NOT BE RESPONSIBLE FOR ANY DAMAGE AS A RESULT OF THE INCORRECT INSTALLATION OR USE OF THIS PRODUCT. IT IS RECOMMENDED THAT A QUALIFIED AUTOMOTIVE TECHNICIAN PERFORMS THIS INSTALLATION.

### Description

Get a floor jack or lift underneath your vehicle with Proflow's car ramps. These ramps are ideal for the long storage of vehicles and for lifting your vehicle without damaging the underbody. They are also great to use at the track in-between sessions when you are letting your brakes cool down or if you quickly need to get under the car. These low-profile service ramps feature a durable plastic construction with a honeycomb design that discourages moisture build-up under your tyres. Built-in wheel stops prevent your car from rolling over the ramps and they have a 1000kg weight limit each (total 2000kg). Carry bag is also included.

### Specifications

- Length: 690mm
- Width: 195mm
- Lift Height: 63mm
- Total Height: 80mm

### Warnings

- Always place ramps on a sturdy flat surface when in use.
- Do not get underneath the vehicle using these ramps unless supported by a secondary safety device such as jack stands. Always obey max load rating capacity: 1000kg per ramp.
- Inspect ramps before use for any defects or damage as a result of previous use. If a defect is found, please discard the item immediately. This could reduce the weight bearing capacity of the ramps and may result in injury or death.
- Always slowly drive the vehicle onto the ramps with guidance from a person outside of the vehicle.
- Always ensure the wheels are perfectly straight and aligned before proceeding to drive onto the ramps.
- Apply the parking brake or chock a wheel when the vehicle is stationary on the ramps.