



INSTALLATION MANUAL

Ford FG Throttle Body Adaptor

PFEWD300-FGBK

WARNING: PLEASE READ ALL INSTRUCTIONS BEFORE PROCEEDING. PROFLOW WILL NOT BE RESPONSIBLE FOR ANY DAMAGE AS A RESULT OF THE INCORRECT INSTALLATION OF THIS PRODUCT. IT IS RECOMMENDED THAT A QUALIFIED AUTOMOTIVE TECHNICIAN PERFORMS THIS INSTALLATION.

TYPICAL INSTALLATION

1. Place the 76 x 2.0 mm o-ring into the internal groove underneath the adaptor. Lubricate this o-ring and ensure it is securely in its groove before proceeding.
2. Place the 4x spacers on each corner of the factory throttle body.
3. Place the throttle body adaptor over the top of the factory throttle body while ensuring the o-ring beneath is still seated correctly.
4. Using the supplied M6 x 50mm screws, fasten the throttle body adaptor by hand-tightening each screw evenly. Torque these screws to approximately 8 Nm. Ensure the o-ring beneath is not being pinched or has accidentally moved out of its groove.

Note: some shimming may be required for each spacer as the pad heights for the factory throttle body may vary slightly between castings.

5. Install the intercooler clamp (not included) onto the throttle body with the provided o-ring.