



Installation Instructions

Handheld Tube Flaring Tool

PFEFLTL


Included Items	QTY
Handheld Flaring Tool 1/8" To 3/4" Tube	1

WARNING: PLEASE READ ALL INSTRUCTIONS BEFORE PROCEEDING. PROFLOW WILL NOT BE RESPONSIBLE FOR ANY DAMAGE AS A RESULT OF THE INCORRECT USE OF THIS PRODUCT.

1. Select the die for the size of your tube by lifting the lock mechanism.
2. Slide the tube into place. Do not clamp the tube into place yet.



3. Push the tube up to the arm which indicates how far to push the tube through before flaring.
4. Clamp the tube down by rotating the handle until tight, ensuring the tube does not move.



5. Turn the handle slowly to apply the flare.



6. Inspect the flare and ensure there is no burring or imperfections.



PROFLOW LIMITED WARRANTY

This Proflow product is warranted to be free from defects in materials and workmanship for a period of one year from the original date of purchase. No warranty claim will be valid without authentic, dated proof of purchase. This warranty is to the original retail purchaser and none other and is available directly from Proflow and not through any point of distribution or purchase.